



## Technical data

Substance	
Backing	special paper with reinforcement layer
Adhesive	waterproof SOLID adhesive
Release film	siliconized paper

  

Attribute	Regulation	Value
Colour		light blue
Bonding requirement, non-aged/aged	DIN 4108-11	passed
Application temperature		above -10 °C ; 14 °F
Temperature resistance		permanent -40 °C to 90 °C ; -40 °F to 194 °F
Storage		cool and dry

## Application

For the permanent airtight and secure adhesion of the overlaps of vapour retarder and airtightness membrane and the indoor joints between such membranes. Also suitable for bonding butt joints between wood-based panels.

## Advantages

- ✓ Ensures reliable building components thanks to waterproof SOLID adhesive
- ✓ Particularly durable: adhesion for 100 years, independently tested and confirmed
- ✓ Easy to work with: paper backing, can be torn off by hand
- ✓ Construction in adherence with standards: for airtight bonding in accordance with DIN 4108-7, SIA 180 and RT 2012
- ✓ Excellent values in the hazardous substance test, has been tested according to the ISO 16000 evaluation scheme

## Substrates

Clean subsurfaces before sticking.

Adhesion to frozen surfaces is not possible. There must be no water-repellent substances (e.g. grease or silicone) on materials to be bonded.

Subsurfaces must be sufficiently dry and stable.

Permanent adhesion is achieved on all pro clima interior membranes and on other vapour retarder and airtight membranes (e.g. those made of PE, PA, PP and aluminium).

Bonding and joints are possible on planed and painted wood, hard plastics and metal (e.g. pipes, windows etc.), hard wood-based panels (chipboard, OSB, plywood panels).

The best results in terms of structural stability are achieved on high-quality subsurfaces.

It is your responsibility to check the suitability of the subsurface; adhesion tests are recommended in certain cases.

Pretreatment with TESCON PRIMER is recommended in the case of subsurfaces with insufficient stability.

UNI TAPE 4 cm can only be used to for bonds on hard substrates (e.g. when laying on rafters lengthwise).

## General conditions

The bonds should not be subjected to tensile strain.

Once membranes have been stuck, the weight of the insulation material must be supported by laths. Adhesion should be supported by battens if necessary.

Press firmly to secure the adhesive tapes in place. Ensure that there is sufficient resistance pressure. Airtight seals can only be achieved on vapour retarding membranes that have been laid without folds or creases. Ventilate continuously and systematically to prevent build-up of excessive humidity; use a dryer if necessary.



The information provided here is based on practical experience and the current state of knowledge. We reserve the right to make changes to the recommended designs and processing or to make alterations due to technical developments and associated improvements in the quality of our products. We would be happy to inform you of the current technical state of the art at the time you use our products.

Further information about the application and construction can be found in the pro clima planning documentation. For queries please call the pro clima technical hotline on +49 (0)6202 278245.

**MOLL**  
**bauökologische Produkte GmbH**  
 Rheinalstraße 35 - 43  
 D-68723 Schwetzingen  
 Fon: +49 (0) 62 02 - 27 82.0  
 eMail: info@proclima.de

