Installation instructions TESCON® NAIDECK mono

Installation steps



1. Reliable sealing

TESCON NAIDECK mono has a very free- flowing butyl adhesive. This adhesive is pulled into the hole created when the nail or screw is fitted, thus sealing this hole.



3. Rub firmly to secure the tape in place

This step can be carried out in a manner that is kinder to your hands by using the pro clima PRESSFIX application tool.



2. Sticking the tape in place

Centre the nail sealing tape on the counter batten or the exterior membrane to be sealed, and gradually stick it in place.



4. Aligning and fastening the counter batten

Put the counter batten in place and fasten completely using nails or screws. The counter batten and TESCON NAIDECK mono must lie flat on the exterior membrane with sufficient pressure. You're finished!

Substrates

Clean subsurfaces before sticking.

Adhesion to frozen surfaces is not possible. There must be no water-repellent substances (e.g. grease or silicone) on materials to be bonded. Subsurfaces must be sufficiently dry and stable.

TESCON NAIDECK mono can be used on all pro clima exterior membranes, on other underlay and wall lining membranes (e.g. those made of PP and PET) and with MDF panels and wood-fibre underlay panels.

The best results in terms of structural stability are achieved on level, unstructured subsurfaces.

It is your responsibility to check the suitability of the subsurface; adhesion tests are recommended in certain cases.

Pretreatment with TESCON PRIMER is recommended in the case of subsurfaces with insufficient stability.

General conditions

Perforation seals will only be effective on roof lining membranes that have been installed with no folds or creases.

Install TESCON NAIDECK mono with no interruptions between the counter battens and the roof lining membrane. This ensures that perforations that may arise when the roof battens are being fastened will also be sealed.

Adhesion can be carried out to the counter batten or to the subsurface that is to be sealed. Press firmly to secure the tape in place.



The information provided here is based on practical experience and the current state of knowledge. We reserve the right to make changes to the recommended designs and processing or to make alterations due to technical developments and associated improvements in the quality of our products. We would be happy to inform you of the current technical state of the art at the time you use our products.

Further information about the application and construction can be found in the pro clima planning documentation. For queries please call the pro clima technical hotline on +49 (0)6202 278245.

MOLL bauökologische Produkte GmbH Rheintalstraße 35 - 43 D-68723 Schwetzingen

Fon: +49 (0) 62 02 - 27 82.0 eMail: info@proclima.de

